SYSTEM SENSITIVITY

()

'The signal-to-noise ratio is used to define the system sensitivity. The limit of quantitation (corresponding to a signal-to-noise ratio of 10) is equal to or less than the reporting threshold.'

- What does it mean?
- Does the system sensitivity requirement apply to both tests and assays?
 How is the S/N ratio calculated?